



Selected - Semiconductor Manufacturing-oriented Engineering


- Focused on manufacturing-oriented engineering using Calibre RET/OPC and lithography workflows for top European foundries.
- Executed ILT/OPC simulation, OPC-Verify checks, multi-patterning analysis, and SRAF optimization for next-generation nodes.
- Built manufacturable layout strategies and improved wafer pattern fidelity through lithography modeling and process-aware tuning.
- Developed and validated MDP/JobDeck structures, including MPC, ModelFlow, LithoView, and Workbench integrations.
- Supported GlobalFoundries, STMicroelectronics, Infineon, and Intel via on-site guidance, remote troubleshooting, and lithography engineering collaboration.

Calibre Products Portfolio

Backend manufacturing



Calibre OPC - Inverse Lithography Technology



A conventional optical proximity correction. The **blue L-like shape** is what chip designers would like print on the wafer, in **green** is the shape after applying optical proximity correction(OPC), and the **red contour** is how the shape is actually printed.

In semiconductor device fabrication, The **inverse lithography technology (ILT)** is an approach to photomask design.

An approach to solve an inverse imaging problem: to calculate the shapes of the openings in a **photomask ("source")** so that the passing light produces a good approximation of the **desired pattern ("target")** on the illuminated material, typically a **photoresist**.


As such, it is treated as a mathematical optimization problem of a special kind, because usually an analytical solution does not exist.

In conventional approaches known as the optical proximity correction (OPC) a "target" shape is augmented with carefully tuned rectangles to produce a "Manhattan shape" for the "source", as shown in the illustration.


The ILT approach generates curvilinear shapes for the "source", which deliver better approximations for the "target".

Calibre OPC outcome – Inconsistency

OPC -1x1mm² widow clip




2x2mm² window clip error




"The edge **post-OPC** feature appears to be undersized. The CUT layer analysis indicates post-OPC mask errors, as expected. The observed CD (~81 nm) deviates significantly from the target CD (~87 nm), with no apparent justification for the observed asymmetric shape."

Calibre OPC – No ripple generation observed due to the absence of inter-feature fragments




OPC simulation



A conventional optical proximity correction. The **green L-like shape** is what chip designers would like printed on the wafer, in **purple** is the shape after applying optical proximity correction(OPC), and the **red contour** is how the shape is actually printed.

Calibre Curvilinear MDP Support New Fracture Formats for Multigons



- The Calibre Curvilinear MDP solution enables the support of new Multibeam formats in the fracture and verification flows.
- Calibre Fracture commands are updated to support the new Multibeam fracture formats.
 - FRACTURE NUFLARE_MBFR now supports version 2.1.
 - FRACUTER OASIS_MBW now supports version 3.0.



Calibre OPCverify Curvilinear Verification for Multigons


- Calibre OPCverify is updated to address the challenges of curvilinear verification for multigons.
- In 2024.4 release, four spline-based checks are production released to support post-OPC verification on multigon layers.

Angle check on a multigon layer using `spline_angle` command.




Distance checks on a multigon layer using `spline_distance` command.

`spline_depth_width` checks minimum width of a multigon using its depth as a constraint.




`spline_dw_ratio` checks the maximum depth-to-width ratio for multigons on a layer.

Calibre OPCverify Multigon Support - spline_distance check



Red—SD, non-Manhattan region
Green—SD, non-Manhattan edge
Orange—MD, non-Manhattan region
Black—MD, non-Manhattan edge




Spline distance

Properties		
Type	Attribute	Value
User	min	0.00653758


Measure distance

Properties		
Type	Attribute	Value
User	min	0.0065102



Green — separation=90nm
Pink — separation_factor=3.0
Yellow — separation_factor=3.4

- An example of Spline distance(SD) check performed on MULTIGON.
 - In comparison, Measure distance(MD) is performed on PWL(converted from Multigon with dev=1dbu).




Pink—non-Manhattan edge
Green—non-Manhattan region
Red—pinpoint gauges
Black—pinpoint markers

Error marker

Calibre Mask Process Correction(MPC)


The Calibre Mask Process Correction family of **rule and model-based products** is used in advanced photomask manufacturing to correct for **systematic mask lithography and process error sources** to ensure that the mask critical dimension signature is within specification




Calibre Standalone Curvilinear Mask Rule Checks (MRC) for Multigons

- Calibre provides new curvilinear MRC methodologies to support the requirements of leading-edge mask manufacturing through key innovations in native curvilinear data handling and representation techniques.
- New standalone SVRF commands are available for curvilinear MRC checks on multigons.
 - RET SPLINE_ANGLE checks the angle of splines on a multigon layer.
 - RET SPLINE_DEPTH_WIDTH checks the minimum width of a multigon shape.
 - RET SPLINE_DISTANCE measures the distance between spline sections on multigon layers.
 - RET SPLINE_DW_RATIO computes the depth-to-width ratio for multigon shapes.


External Distance Check Example




Internal Distance Check Example



Spike Detection Example




Depth-Width Check Example




Calibre Mask Process Correction(MPC) – Reduces the CD model error

IsoLn CD model error when ignoring e-beam writer corrections for Fogging









IsoLn CD model error reduced from over ± 2 nm to ± 0.5 nm when including e-beam writer corrections for Fogging



Calibre Capabilities to Simplify Irregular Shape Checking

Photonics, through-silicon via, & packaging checks

	Circle	Stadium	Teardrop
Recognize & separate	<ul style="list-style-type: none"> INSIDE CELL [NOT] CIRCLE 	<ul style="list-style-type: none"> INSIDE CELL [NOT] STADIUM 	<ul style="list-style-type: none"> INSIDE CELL [NOT] TEARDROP 
Check Dimension & Ref Output	<ul style="list-style-type: none"> DFM CIRCLE ANALYZE DFM CIRCLE ANALYZE (center/ring) 	<ul style="list-style-type: none"> DFM STADIUM ANALYZE DFM STADIUM ANALYZE (center/ring) 	<ul style="list-style-type: none"> DFM TEARDROP ANALYZE DFM TEARDROP ANALYZE (center/ring) 

Calibre Capabilities to Simplify Irregular Shape Design Rule Check DFM Circle Analyze

```
VARIABLE minimum_radius 1.0
VARIABLE maximum_radius 2.0
VARIABLE minimum_curvature_width 0.1
VARIABLE maximum_curvature_width 0.2
```

```
LAYER M1 54 350
```

```
// To obtain a Circle with a width of 0.14um (>=0.14)
```

```
circle_props = DFM CIRCLE ANALYZE M1
circle_ringL14 = DFM PROPERTY circle_props
```

```
[inrad = PROPERTY(circle_props, INRADIUS)]
```

```
[outrad = PROPERTY(circle_props, OUTRADIUS)]
```

```
[annulus_in = PROPERTY(circle_props, ANNULUS_INRADIUS)]
```


```
[ratio = PROPERTY_REF(inrad)/PROPERTY_REF(outrad)] > 0.9
```

```
[enclosing_width = 2*(PROPERTY(circle_props, OUTRADIUS))]
```


```
[width = (PROPERTY_REF(annulus_in)!=0) ? (PROPERTY_REF(inrad)+PROPERTY_REF(outrad))/2 -
PROPERTY_REF(annulus_in): PROPERTY_REF(inrad)+PROPERTY_REF(outrad)] >= minimum_curvature_width <=
maximum_curvature_width
```

```
[radius = (PROPERTY_REF(annulus_in)!=0) ? (PROPERTY_REF(width))+PROPERTY_REF(annulus_in):
(PROPERTY_REF(inrad)+PROPERTY_REF(outrad))/2] >= minimum_radius <= maximum_radius
```

```
DFM_out { DFM RDB circle_ringL14 "dfm.rdb" ALL CELLS CHECKNAME "%_L_" }
```



Python Code and its output: S-bend for SiN waveguide (Cubic Bezier segments)



```
# S-bend (SiN waveguide) – cubic Bézier 2-segment example
import numpy as np
import matplotlib.pyplot as plt

# Segment 1 control points (P0..P3)
P0 = np.array([0.0, 0.0])
P1 = np.array([2.0, 0.0])
P2 = np.array([3.0, 1.5])
P3 = np.array([5.0, 1.0]) # mid point

# Segment 2 control points (Q0..Q3)
Q0 = P3
Q1 = np.array([7.0, 0.5])
Q2 = np.array([8.0, 2.5])
Q3 = np.array([10.0, 2.0])

def cubic_bezier(A, B, C, D, n=300):
    t = np.linspace(0, 1, n)
    return (
        ((1 - t)**3)[ :, None] * A +
        (3 * ((1 - t)**2 * t))[ :, None] * B +
        (3 * ((1 - t) * t**2))[ :, None] * C +
        (t**3)[ :, None] * D
    )

c1 = cubic_bezier(P0, P1, P2, P3, n=200)
c2 = cubic_bezier(Q0, Q1, Q2, Q3, n=200)
curve = np.vstack([c1, c2[1:]]) # join without duplicating the midpoint
```


(Code continued)



Cubic Bezier curve in mathematics

$$B(t) = (1-t)^3 P_0 + 3t(1-t)^2 P_1 + 3t^2(1-t)P_2 + t^3 P_3, \quad 0 \leq t \leq 1$$

Python Code and its output: S-bend for SiN waveguide (Cubic Bezier segments)



(Code output)

```
29
30     # Plot: thick centerline as waveguide, plus control polygons/points
31     plt.figure(figsize=(8, 3.5))
32     plt.plot(curve[:, 0], curve[:, 1], linewidth=6) # thick centerline = waveguide
33     plt.plot([P0[0], P1[0], P2[0], P3[0]], [P0[1], P1[1], P2[1], P3[1]], linestyle='--', marker='o', markersize=4)
34     plt.plot([Q0[0], Q1[0], Q2[0], Q3[0]], [Q0[1], Q1[1], Q2[1], Q3[1]], linestyle='--', marker='o', markersize=4)
35
36     plt.scatter([P0[0], Q3[0]], [P0[1], Q3[1]], zorder=5)
37     plt.text(P0[0], P0[1]-0.2, "input", va='top')
38     plt.text(Q3[0], Q3[1]+0.2, "output", va='bottom')
39
40     plt.title("S-bend for SiN waveguide (cubic Bézier segments)")
41     plt.xlabel("x (μm)")
42     plt.ylabel("y (μm)")
43     plt.axis('equal')
44     plt.grid(True)
45     plt.tight_layout()
46     plt.show()
```

PROBLEMS OUTPUT DEBUG CONSOLE TERMINAL PORTS

Python Code and its output: S-bend for SiN waveguide (Cubic Bezier segments)

